

# ***Durrelle Racing Products***

*1930 Chisholm Cir  
Elizabeth, CO 80107  
Phone 303.646.0935  
Fax 303.646.0975*

## **Instructions for Lowered seat pad and cover installations**

**With a small straight blade screwdriver remove the staples from underneath seat base. Remove your seat cover and foam.**

**Set new seat pad in place on seat base. You may want to use a little spray adhesive but it is not necessary.**

**Hook cover over the front edge of foam and seat base.**

**Stretch the cover straight back so the Saddleman logo is at the end of the seat. Apply two staples to the bottom side to secure its position.**

**Start from the middle of seat and pull down the sides and staple to base making sure to keep the seam even on each side. Staple every 4-6 inch's to start then go back and increase staples to every inch for a nice wrinkle free fit.**

**You might have to remove some material around the seat hook in the front of the seat to allow it to catch the button on the gas tank without any interference. You will have to make a cut in the material around the rear seat mounts in order for it to fit around the mount.**

**If you have any questions please call!**